

MR SCAN

TRANSFER SETUP CHECKLIST

- Liaise with MR for a time. 60511/60532
- Check patient has wristband
- MR safety checklist (paper) have been complete (is patient suitable for scan).
- Ensure Best interest meeting (EPR), mental capacity assessment (EPR), form 4 (paper).
- PET-T trolley should not be used (will not fit in lifts in Turnberg building).
- Transfer bag (sealed and checked).
- Drug boxes (sealed red and clear)
- Portable ventilator with sufficient charge & tubing. Attach to wall O2 and medical team will set up.
- Use full F size O2 cylinder from back of bedspace.
- Monitor with sufficient charge.
- Mapleson C circuit with O2 flow connector.
- Remove and disconnect flowtrons.
- Disconnect any unnecessary infusions. TPN can be stopped but must remain connected.
- Stop, aspirate, and disconnect feed. Stop VRII.
- Draw up infusions into braun pumps (Check charge and consider spare drugs depending on infusion rate). Place into transfer brackets no more than two pumps per bracket. **Double all infusion lines.**
- Check blood glucose before departure > 4 mmol/l.
- Disconnect mattress.
- Book porters in a timely manner.