

THEATRE TRANSFER SETUP CHECKLIST

- Liaise with theatre for a time.
- Check patient has wristband.
- Ensure surgical pathway and consent has been complete.
- If consent 4 ensure best interest meeting is complete (EPR).
- Check G&S has been sent if applicable.
- Equipment from CCU should be used and then returned with patient.
- PET-T trolley should not be used.
- Portable ventilator with sufficient charge & tubing. Attach to wall O2 and medical team will set up (if ventilated).
- Use full F size O2 cylinder from back of bedspace.
- Draw up infusions into braun pumps (check charge and consider spare drugs depending on infusion rate). Place into transfer brackets no more than two pumps per bracket.
- Unplug brick when theatre staff arrive. If ventilated use T1 handle to get Co2 trace.
- Remove and disconnect flowtrons.
- Disconnect any unnecessary infusions. TPN can be stopped but must remain connected.
- Stop, aspirate, and disconnect feed. Stop VRII.
- Check blood glucose before departure > 4 mmol/l.
- Disconnect mattress.
- Update NOK on departure/return.